



TANDEMKROSS Buck Pro Basepad Installation V1.1

www.tandemkross.com

For more info or support contact CustomerService@tandemkross.com

Attention:

Before you begin, be certain that the firearm is clear and safe.

The TANDEMKROSS Buck Pro Basepad includes the following items:

1. Basepad
2. Speed Nut Holder
3. Nut
4. 8/32 1/4" socket cap screw
5. Metal Retaining Clip
6. Allen Key

Step 1: Place the Nut into the Speed Nut Holder. Note: You may need to punch out the insert in the middle of the nut holder. This is easy to do by setting the edge of the plastic speed nut holder on the edge of the nut and pressing the middle out with the allen key.

Step 2: Assemble the basepad and Retaining Clip with the Socket Cap screw and Speed Nut. Place the retaining clip into the pocket in the bottom of the basepad. Insert the speed nut into the retaining clip inline with the hole. From the bottom insert the socket cap screw and begin to thread into the nut. Leave the assembly loose so that there is enough movement to slide onto the bottom of the magazine.

Step 3: Slide the assembly onto the bottom of the magazine starting from the back of the magazine. Tilting the assembly at an angle and ensuring that the speed nut stays in place under the magazine shoe.

Step 4: Align and Tighten. Insert the empty magazine into your pistol and align the basepad with your grip by sliding it either forward or back. Different models of Buck Mark pistols have different positions for where the basepad looks best. Once aligned where desired, tighten the screw so the basepad is tight and does not move.



